



RDF300, RDF300.02  
RDF340, RDF600



RDF300.02/VB



RDF400.01  
RDF600T

## Flush-mounted room thermostats

## RDF300... RDF340 RDF400... RDF600...

for 2-pipe, 2-pipe with el. heater and 4-pipe fan coil units  
for use with compressors in DX type equipment

- **RDF300 / RDF400 / RDF600/RDF600T:**  
AC 230 V operating voltage, on/off or 3-position control outputs
- **RDF340...:**AC 24 V, operating voltage, DC 0...10 V control outputs
- Output for 3-speed or 1-speed fan
- 2 multifunctional inputs for keycard contact, external sensor, etc.
- Operating modes: Comfort, Economy and Protection
- Automatic or manual fan speed control
- Automatic or manual heating/cooling changeover
- Adjustable commissioning and control parameters
- Minimum and maximum setpoint limitation
- User and parameter settings can be retained or restored with power loss

### Additional features

- Backlit LCD (RDF300.02, RDF300.02/VB, RDF400.01, RDF600, RDF600T)
- Infrared remote control receiver (RDF400.01, RDF600T)
- Auto Timer mode with 8 programmable timers (RDF400.01, RDF600T)

### Type of mounting / suitable conduit boxes

- RDF600... for round CEE box, with min 60 mm diameter, min 40 mm depth
- RDF3... / RDF400... for recessed square box with 60.3 mm fixing centers

## Use

---

### Applications

To control the room temperature in individual rooms and zones that are:

- Heated or cooled with 2-pipe fan coil units
- Heated or cooled with 2-pipe fan coil units with electrical heater
- Heated and cooled with 4-pipe fan coil units
- Heated or cooled with compressor in DX type equipment
- Heated or cooled with compressor in DX type equipment with electrical heater
- Heated and cooled with compressor in DX type equipment

The RDF300... / RDF400... / RDF600... control:

- One 1- or 3-speed fan
- One or 2 on/off valve actuators
- One on/off valve actuator and one 1-stage electrical heater
- One 3-position valve actuator
- One 1-stage compressor in DX type equipment or one 1-stage compressor with electrical heater

The RDF340... controls:

- One 1- or 3-speed fan
- One or 2 DC 0...10 V valve actuators
- One DC 0...10 V valve actuator and one modulating electrical heater (DC 0...10 V)

Used in systems with:

- Heating or cooling mode
- Automatic heating/cooling changeover
- Manual heating/cooling changeover
- Heating and cooling mode (e.g. 4-pipe system)

## Functions

---

- Maintain room temperature via built-in temperature sensor or external room temperature / return air temperature sensor
- Automatic or manual changeover between heating and cooling mode
- Select applications via DIP switches
- Select operating mode via the operating mode button on the thermostat
- 1- or 3-speed fan control (automatic or manual)
- Display current room temperature or setpoint in °C and/or °F
- Minimum and maximum setpoint limitation
- Key lock (automatic and manual)
- 2 multifunctional inputs, freely selectable for:
  - Operating mode switchover contact (key card)
  - Automatic heating/cooling changeover sensor
  - External room temperature or return air temperature sensor
  - Dewpoint sensor
  - Electrical heater enable
  - Alarm input
- Advanced fan control function, i.e. fan kick, fan start, selectable fan operation (enable, disable or depending on heating or cooling mode)
- Purge function together with 2-port valve in a 2-pipe changeover system
- Reminder to clean filters
- Floor heating temperature limit
- Reload factory settings for commissioning and control parameters
- 7-day time program: 8 programmable timers to switch over between Comfort and Economy mode (RDF400.01 / RDF600T)
- Backlit LCD (RDF300.02 / RDF300.02/VB / RDF400.01 / RDF600 / RDF600T)
- Optional infrared remote control (RDF400.01 / RDF600T)

## Applications

The thermostat supports the following applications, which can be configured by DIP switches on the inner side of the thermostat's front. Depending on the type, on/off or modulating control outputs are available.

### Applications for fan coil systems

Application and output signal, DIP switches, diagram	
<ul style="list-style-type: none"> <li>• <b>2-pipe fan coil unit ON/OFF</b> (heating or cooling)</li> <li>• <b>2-pipe fan coil unit modulating, DC 0...10 V</b> (heating or cooling)</li> </ul>	<p>RDF300... RDF400... RDF600...</p> <p>RDF340</p>
<ul style="list-style-type: none"> <li>• <b>2-pipe fan coil unit ON/OFF</b> (heating or cooling) with electrical heater</li> <li>• <b>2-pipe fan coil unit modulating, DC 0...10 V</b> (heating or cooling) with electrical heater</li> </ul>	<p>RDF300... RDF400... RDF600...</p> <p>RDF340</p>
<ul style="list-style-type: none"> <li>• <b>2-pipe fan coil unit modulating, 3-position</b> (heating or cooling)</li> </ul>	<p>RDF300... RDF400... RDF600...</p> <p>RDF340</p>
<ul style="list-style-type: none"> <li>• <b>4-pipe fan coil unit ON/OFF</b> (heating and cooling)</li> </ul>	<p>RDF300... RDF400... RDF600...</p> <p>RDF340</p>

V1 Heating or heating/cooling valve actuator  
V2 Cooling valve actuator

E1 Electrical heater

M1 3-speed or single-speed fan  
B1 Return air temperature sensor or external room temperature sensor (optional)  
B2 Changeover sensor (optional)

Application and output signal, DIP switches, diagram	
<ul style="list-style-type: none"> <li><b>Chilled / heated ceiling ON/OFF</b> (heating or cooling)</li> <li><b>Chilled / heated ceiling modulating, DC 0...10 V</b> (heating or cooling)</li> </ul>	<ul style="list-style-type: none"> <li>RDF300... RDF400... RDF600...</li> <li>RDF340</li> </ul>
<ul style="list-style-type: none"> <li><b>Chilled / heated ceiling ON/OFF</b> (heating or cooling) with electrical heater</li> <li><b>Chilled / heated ceiling modulating, DC 0...10 V</b> (heating or cooling) with electrical heater</li> </ul>	<ul style="list-style-type: none"> <li>RDF300... RDF400... RDF600...</li> <li>RDF340</li> </ul>
<ul style="list-style-type: none"> <li><b>Chilled / heated ceiling modulating, 3-position</b> (heating or cooling)</li> </ul>	<ul style="list-style-type: none"> <li>RDF300... RDF400... RDF600...</li> </ul>
<ul style="list-style-type: none"> <li><b>Chilled ceiling and radiator ON/OFF</b> (heating and cooling)</li> </ul>	<ul style="list-style-type: none"> <li>RDF300... RDF400... RDF600...</li> <li>RDF340</li> </ul>

V1 Heating or heating / cooling valve actuator

V2 Cooling valve actuator


E1 Electrical heater

B1 Return air temperature sensor or external room temperature sensor (optional)

B2 Changeover sensor (optional)

D3 Dewpoint sensor

## Applications for heat pump systems



N1 Thermostat  
Terminal Y10/Y11: Heating (H&C) or Heating/Cooling  
Terminal Y20/Y21: Cooling (H&C)

E1 Electrical heater

B1 Return air temperature sensor or external room temperature sensor (optional)

D3 Dewpoint sensor

## Type summary

Product number	Stock number	Features								Color
		Operating Voltage	Control outputs			Time program	Backlit LCD	Infrared receiver <sup>1)</sup>	Suitable conduit box <sup>2)</sup>	
			on/off	3pt	DC 0..10 V					
<b>RDF300</b>	RDF300	AC 230 V	✓	✓					square	White
<b>RDF300.02</b>	RDF300.02	AC 230 V	✓	✓			✓		square	White
<b>RDF300.02/VB</b>	S55770-T427	AC 230 V	✓	✓			✓		square	Black
<b>RDF400.01</b>	RDF400.01	AC 230 V	✓	✓		✓	✓	✓	square	White
<b>RDF340</b>	RDF340	AC 24 V			✓				square	White
<b>RDF600</b>	S55770-T291	AC 230 V	✓	✓			✓		round	White
<b>RDF600T</b>	S55770-T292	AC 230 V	✓	✓		✓	✓	✓	round	White

1) Infrared remote control is to be ordered as separate item

2) Square conduit box e.g. ARG71.










Round conduit box min 60 mm diameter and min 40 mm depth

## Ordering

- When ordering, indicate both product number / SSN number and name:  
E.g. **RDF600 / S55770-T291 room thermostat**
- Order the **IRA211 (S55770-T166)** infrared remote control separately (for RDF400../RDF600...).
- Order valve actuators separately.















## Equipment combinations

On / off actuators

Designation		Product no.	Data Sheet <sup>1)</sup>
Cable temperature sensor or changeover sensor, cable length 2.5 m NTC (3 kΩ at 25 °C)		<b>QAH11.1</b>	1840
Room temperature sensor NTC (3 kΩ at 25 °C)		<b>QAA32</b>	1747
Cable temperature sensor, cable length 4 m NTC (3 kΩ at 25 °C)		<b>QAP1030/UFH</b>	1854
Condensation monitor		<b>QXA21..</b>	A6V10741072
Electromotoric ON/OFF actuator		<b>SFA21...</b>	4863
Electromotoric ON/OFF valve and actuator (only available in AP, UAE, SA and IN)		<b>MVI.../MXI...</b>	A6V11251892
Zone valve actuators (only available in AP, UAE, SA and IN)		<b>SUA...</b>	4832
Thermal actuator (for radiator valve)		<b>STA23...</b>	4884
Thermal actuator (for small valves 2.5 mm)		<b>STP23...</b>	4884




3-position actuators

DC 0...10 V actuators

Designation		Product no.	Data Sheet *)
Electrical actuator, 3-position (for radiator valve)		<b>SSA31...</b>	4893
Electrical actuator, 3-position (for small valve 2.5 mm)		<b>SSP31...</b>	4864
Electrical actuator, 3-position (for small valve 5.5 mm)		<b>SSB31...</b>	4891
Electrical actuator, 3-position (for 2- and 3-port valves / V...P45)		<b>SSC31...</b>	4895
Electromotoric actuator, DC 0...10 V (for valves 5.5 mm)		<b>SAS61..</b>	4581
Electromotoric actuator, DC 0...10 V (for valves 5.5 mm)		<b>SAT61..</b>	4584
Electrical actuator, DC 0...10 V (for radiator valves)		<b>SSA61..</b>	4893
Electrical actuator, DC 0...10 V (for 2- and 3-port valves/V...P45)		<b>SSC61..</b>	4895
Electrical actuator, DC 0...10 V (for small valves 2.5 mm)		<b>SSP61..</b>	4864
Electrical actuator, DC 0...10 V (for small valves 5.5 mm)		<b>SSB61..</b>	4891
Electromotoric actuator, DC 0...10 V (for valves 5.5 mm)		<b>SAS61..</b>	4581
Electromotoric actuator, DC 0...10 V (for valves 5.5 mm)		<b>SAT61..</b>	4584
Electrothermal actuator, AC 24 V, NC, DC 0...10 V, 1 m		<b>STA63</b>	4884
Electrothermal actuator, AC 24 V, NO, DC 0...10 V, 1 m		<b>STP63</b>	4884

\*) The documents can be downloaded from <http://siemens.com/bt/download>.

Accessories

Designation		Product no.	Data Sheet
Changeover mounting kit (50 pcs/package)		<b>ARG86.3</b>	N3009
Plastic mounting spacer for flush-mounted thermostats RDF3.. RDF400... for increasing the headroom in the conduit box by 10 mm		<b>ARG70.3</b>	N3009
Conduit box for flush-mounted thermostat RDF3.. RDF400...		<b>ARG71 / S55770-T137</b>	N3009

The thermostat consists of 2 parts:

- Front panel accommodating the electronics, operating elements and built-in room temperature sensor.
- Mounting base with the power electronics.


The rear of the mounting base contains the screw terminals Slide the front panel in the mounting base and snap on.

**Operation and settings**  
RDF300.../RDF340...  
RDF600




1. Operating mode selector / Protection
2. Change fan operation
3. Adjust setpoint and control parameters

RDF400...  
RDF600T



1. Change operating mode selector
2. Change fan operation
3. Adjust setpoint, control parameters and time of day
4. Auto Timer program
5. Protection
6. Set time of day and weekday
7. Confirm
8. Infrared receiver

**Display**




1. Operating mode  
  - ⏻ Protection
  - 🕒 Auto Timer mode \*
  - ☀️ Comfort
  - 🌙 Economy

2. Display room temperature, setpoints and control parameters.  
    - 🏠 Symbol used to display the current room temperature
  3. Heating/cooling mode  
    - ⚙️ Cooling mode
    - 🔥 Heating mode,
    - ⚡ Aux Electrical heater active
  4. Fan mode  
    - 🌀 Auto Auto fan active
    - 🌀 Fan speed low, medium, high
  5. Additional user information (RDF3xx) or current time of day (RDF400 / RDF600T)
  6. Weekday 1..7 (1 = Monday/7 = Sunday)\*
  7. Key lock active
  8. Condensation in room (dewpoint sensor active)
  9. Indicate fault or reminder
- \* only on RDF400... / RDF600T



## Mounting and installation

Mount the room thermostat on the conduit box. Do not mount on a wall in niches or bookshelves, behind curtains, above or near heat sources, or exposed to direct solar radiation. Mount about 1.5 m above the floor.



### Mounting / dismounting



- Devices must be mounted on clean, dry indoor place without direct airflow from a heating / cooling device, and not be exposed to dripping or splashing
- RDF3... / RDF400... : In case of limited space in the conduit box use the mounting bracket ARG70.3 to increase the headroom by 10mm
- Before removing the front cover, disconnect the power supply.

### Wiring



See the mounting instructions enclosed with the thermostat:

M3076... for RDF3..., RDF4... ; M3063 for RDF600... .



- Wiring, protection and earthing must be installed in compliance with local regulations.

#### Warning!

#### No internal line protection for supply lines to external consumers (Q1, Q2, Q3, Yxx)

Risk of fire and injury due to short-circuits!

- Adapt the line diameters as per local regulations to the rated value of the installed overcurrent protection device.
- Use only valve actuators rated for AC 230 V on RDF300... / RDF400... / RDF600..
- The AC 230 V mains supply line must have an external fuse or circuit breaker with a rated current of no more than 10 A.
- Isolate the cables of SELV inputs X1-M/X2-M if the conduit box carries AC 230 V mains voltage.
- Inputs X1-M or X2-M of different units (e.g. summer/winter switch) may be connected in parallel with an external switch. Consider overall maximum contact sensing current for switch rating.
- No metal conduits
- No cables provided with a metal sheath
- Disconnect from supply before opening the cover



### Commissioning


Set the thermostat application via the DIP switches before snapping the front panel on the mounting base.

After power is applied, the thermostat carries out a reset during which all LCD segments flash indicating that the reset was correct. After the reset, which takes about 3 seconds, the thermostat is ready for commissioning by qualified HVAC staff. The control parameters of the thermostat can be set to ensure optimum performance of the entire system (see basic documentation P3076).

Note After powerfail the thermostat restarts in the same mode as before.

## Control sequence

- The control sequence may need to be set via parameter P01 depending on the application. The factory setting for the 2-pipe application is "Cooling only"; and "Heating and Cooling" for the 4-pipe application.

Compressor-based application 

- When the thermostat is used with a compressor, the minimum output on-time (parameter P48) and off-time (parameter P49) for Y11/Y21 must be adjusted to avoid damaging the compressor and shortening its life.

Calibrate sensor

- Recalibrate the temperature sensor if the room temperature displayed on the thermostat does not match the room temperature measured (after min. 1 hour of operation). To do this, change parameter P05.

Setpoint and range limitation

We recommend to review the setpoints and setpoint ranges (parameters P08...P12) and change them as needed to achieve maximum comfort and save energy.

## Disposal



The device is considered electrical and electronic equipment for disposal in terms of the applicable European Directive and may not be disposed of as domestic garbage.

- Dispose of the device through channels provided for this purpose.
- Comply with all local and currently applicable laws and regulations.

## Technical data

 Power supply

Rated voltage	RDF300... /400... / 600... RDF340...	AC 230 V SELV AC 24 V $\pm$ 20 % or AC 24 V class 2 (US)
Frequency		50/60 Hz
Power consumption	RDF300... / RDF400.. RDF340... RDF600...	Max. 8 VA Max. 3.5 VA / 0.8 W
External supply line protection (EU)		Circuit breaker max. 10 A Characteristic B, C, D according to EN 60898 or Power source with current limitation of max. 10 A



### No internal fuse

External preliminary protection with max. C 10 A circuit breaker in the supply line required under all circumstances

Outputs

Fan control Q1, Q2, Q3-N	AC 230 V
Rating	5 mA...5(2) A
Control output Y11-N/Y21-N (N.O.)	AC 230 V
Rating	5 mA...5(2) A
Control output Y10-G0/Y20-G0	SELV DC 0...10 V
Resolution	39 mV
Current	Max. $\pm$ 1 mA
Max. total load current through terminal "L" (Qx + Yxx)	Max. 7 A

Inputs

Multifunctional input X1-M/X2-M	
Temperature sensor input:	
Type	NTC (3 k $\Omega$ at 25 °C)
Temperature range	0...49 °C
Cable length	Max. 80 m
Digital input:	
Operating action	Selectable (N.O./N.C.)
Contact sensing	SELV DC 0...5 V/max. 5 mA
Parallel connection of several thermostats for one switch	Max. 20 thermostats per switch
Insulation against mains voltage (SELV)	4 kV, reinforced insulation


	Function input:		
	External temperature sensor, heating/cooling changeover sensor, operating mode switchover contact, dewpoint monitor contact, enable electrical heater contact, alarm contact	Selectable X1: P38 X2: P40	
Operational data	Switching differential, adjustable		
	Heating mode	(P30)	2 K (0.5...6K)
	Cooling mode	(P31)	1 K (0.5...6K)
	Setpoint setting and range		
	Comfort	(P08)	21°C (5...40 °C)
	Economy	(P11-P12)	15°C/30°C (OFF, 5...40 °C)
	Protection	(P65-P66)	8°C/OFF (OFF, 5...40 °C)
	Multifunctional input X1/X2		
	Input X1		Selectable 0...6 3: (P38) operating mode switchover
	Input X2		2: (P40) heating/cooling changeover sensor
Environmental conditions	Built-in room temperature sensor		
	Measuring range		0...49 °C
	Accuracy at 25 °C		< ± 0.5 K
	Temperature calibration range		± 3.0 K
	Settings and display resolution		
	Setpoints		0.5 °C
	Current temperature value displayed		0.5 °C
	Storage		
	Climatic conditions		As per IEC 60721-3-1 Class 1K3
	Transport		
Climatic conditions		As per IEC 60721-3-2 Class 2K3	
Operation			
Climatic conditions		As per IEC 60721-3-3 Class 3K5 <sup>1)</sup>	
Standards and directives	EU Conformity (CE)	RDF3... RDF4... RDF600...	CE1T3076_1 <sup>1)</sup> CE1T3076xx_2 <sup>2)</sup> CE1T3076xx_3 <sup>3)</sup>
	RCM Conformity	RDF3..., RDF600... RDF600...	A5W90002894-A <sup>1)</sup> CE1T3076en-C <sup>1)</sup>
	Degree of protection of housing		
	IP 30 to EN 60529		
Protective class			
II as per EN 60730-1			
Pollution class			
Normal			
Housing flammability class according to UL94			
V-0			
Environmental compatibility	The product environmental declarations CE1E3076_1en (RDF3...) <sup>1)</sup> , A5W00085839A (RDF300.02/VB) <sup>1)</sup> , CE1E3076_2en (RDF4...) <sup>1)</sup> , CE1E3076_4en (RDF600...) <sup>1)</sup> contain data on environmentally compatible product design and assessments (RoHS compliance, materials composition, packaging, environmental benefit, disposal).		
General	Connection terminals		
	Solid wires or prepared stranded wires 1 x 0.4...1.5 mm <sup>2</sup>		
	Housing front color		
RAL 9003 white RAL 9004 black			
Weight	RDF3..., RDF4...		0.220 kg
	RDF600...		0.150 kg

\*) The documents can be downloaded from <http://siemens.com/bt/download>.

1) No condensation is allowed.


## Connection terminals

RDF300.../RDF400...  
RDF600...



- L, N Operating voltage AC 230 V
- Q1 Control output "Fan speed 1 AC 230 V"
- Q2 Control output "Fan speed 2 AC 230 V"
- Q3 Control output "Fan speed 3 AC 230 V"
- Y11, Y21 Control output "Valve" AC 230 V (N.O., for normally closed valves), output for compressor or output for electrical heater
- X1, X2 Multifunctional input for temperature sensor (e.g. QAH11.1) or potential-free switch
- M Measuring neutral for sensor and switch


RDF340...



- G, G0 Operating voltage thermostat AC 24 V
- L Operating voltage for fan AC 230 V
- Q1 Control output "Fan speed 1 AC 230 V"
- Q2 Control output "Fan speed 2 AC 230 V"
- Q3 Control output "Fan speed 3 AC 230 V"
- Y10, Y20 Control output for DC 0...10 V actuator
- X1, X2 Multifunctional input for temperature sensor (e.g. QAH11.1) or switch
- M Measuring neutral for sensor and switch


## Connection diagrams

RDF300..., RDF400..., RDF600...



- N1 Room thermostat RDF300... / RDF400... / RDF600
- M1 3-speed fan
- M2 1-speed fan
- V1...V3 Valve actuator
- E1 Electrical heater
- S1, S2 Switch (keycard, window contact, etc.)
- B1, B2 Temperature sensor (return air temperature, external room temperature, changeover sensor, etc.)
- C1, C2 Compressor

RDF340...



⚠ For US installations use Class 2 rated power supplies. For other installations use circuit breakers with rated current of no more than 10 A.

- N1 Room thermostat RDF340...
- M1 3-speed fan
- M2 1-speed fan
- V1, V2 Valve actuator
- YR DC 0...10 signal converter/current valve
- E1 Electrical heater
- S1, S2 Switch (keycard, window contact, etc.)
- B1, B2 Temperature sensor (return air temperature, external room temperature, changeover sensor, etc.)

# Dimensions

Dimensions in mm

RDF3... RDF400...

RDF600...

